

PARTS LIST

NO.	Part name	QTY
1	handle screw 4x16	2
2	308 handle	1
3	switch(2P)	1
4	Data label	1
5	308top cover	1
6	Motor cover	1
7	screw 4x16	2
8	Power cord press board screw4x16	1
9	Power cord	1
10	bottom cover	1
11	Motor top sealing ring	1
12	A24 motor	1
13	Motor bottom sealing ring	1
14	motor noise reduction sponge	1
15	motor frame	1
16	safety valve	1
17	bottom cover bascket	1
18	bottom cover bascket screw 5x20	10
19	308 clamps	2
20	308 clamps base	2
21	308 clamps handle	2
22	screw 4x12	6
23	308 air-inlet sets sealing ring	1
24	308 air-inlet sets	1
25	air-inlet sets screw 4x16	3
26	screw 4x16	1
27	tank	1
28	308 bottom base	1
29	308 castors	1
30	wheels	1
31	screw 4x12	2
32	1.5m hose	1
33	Electrostatic chain spring	1
34	small nozzle	4
35	dry&wet square brush	4
36	Plastic tube	4
37	manual	1
38	foam filter	1
39	Filter for dry	1

This diagram shows the exploded view of a vacuum cleaner, with parts numbered 1 through 39. The components are organized as follows:

- Top Section (1-10):** Includes the motor housing (1), handle (2), trigger switch (3), motor unit (5), and various screws (6, 7, 8, 9).
- Filter and Motor Assembly (11-18):** Shows the filter housing (11), filter (12), gasket (13), and motor assembly (14-18) with a spring (17) and screw (18).
- Canister (19-21):** The main vacuum canister (19) with a handle (20) and a latch (21).
- Attachments (22-33):** Includes a crevice tool (22), a motorized tool (23), a motor (24), a motor (25), a motor (26), a motor (27), a motor (28), a motor (29), a motor (30), a motor (31), a motor (32), and a motor (33).
- Accessories (34-39):** Includes a brush roll (34), a motor (35), a motor (36), a motor (37), a motor (38), and a motor (39).