

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Cross slot disc head tapping screw	16	18	Flat pad	1
2	Right casing	1	19	Flat pad	1
3	Switch	1	20	Torsion spring	1
4	Anti self locking button	1	21	Chain protective cover	1
5	Cross slot disc head tapping screw	2	22	Guide plate locknut	1
6	Oil pump assembly	1	23	Left casing	1
7	Cross sink self tapping screw	4	24	Speocket	1
8	Gear box cover	1	25	Flat pad	1
9	Oil can lid	1	26	Circlip	1
10	Oiler	1	27	Chain plate	1
11	Bearing insert	1	28	Chain	1
12	Disk teeth	1	29	Chain adjusting screw assembly	1
13	Output axis	1	30	Front cover of housing	1
14	Motor components	1	31	Flat pad	1
15	Plug in seat	1	32	Chain locking screw	1
16	Beush free controller	1	33	Knife holster	1
17	Cross slot disc head tapping screw	1			

ASSEMBLY DIAGRAM

