

PARTS LIST

No.	Description	No.	Description
1	Trigger	14	screw
2	Magnets	15	Upper cover
3	Trigger Spring	16	Right shell
4	screw	17	Switch panel
5	Nuts	18	left shell
6	screw	19	screw
7	Nut holder	20	Pin In
8	Blade holder	21	Battery Pack(87381 not included)
9	Gear box	22	Charger(87381 not included)
10	Motor	23	Oscillating gear
11	Fixed Blade	24	screw
12	Moving Blade	25	Controller
13	screw	26	PCB

[illegible]