

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Self-tapping screw 4x18	4	5-15	Front dustproof cover	1
2	Mechanical screw m4x6	1	5-16	Main axis	1
3	Lampshade	1	5-17	Upper pressing plate	1
4	Headshell decorative part	1	5-18	Motor	1
5-1	Lever complete	4	5-19	Mechanical screw	4
5-2	Decentration positioning block	1	6	Switch knob	1
5-3	Mechanical screw	2	7	Housing	1
5-4	Position shaft	1	8	Self-tapping screw st3x14	8
5-5	Screw	2	9	Lock shrapnel	2
5-6	Head shell	1	10	T tyep rubber pad	4
5-7	Pin	1	11	Controller	1
5-8	Pull rod	1	12	Dust outlet tube	1
5-9	Back dustproof cover	1	13	Lower shell of dust outlet tube	1
5-10	Spring	1	14	Upper shell of dust outlet tube	1
5-11	Shifter fork	1	15	Spring	2
5-12	Bearing	2	16	Self-tapping screw 3x8	2
5-13	Gasket	1	17	Heat-shrinkable tube	2
5-14	Elastic retaining ring	1	18	Magnetic ring 9x5.2x12	1

ASSEMBLY DIAGRAM

