

PARTS LIST

No.	Description	No.	Description
1	Left handle	27	Left swivelling cover
2	Switch button	28	Protect rack
3	Switch button spring	29	Left housing cover
4	Plug in holder	30	Motor
5	Right handle	31	Motor holder
6	Self locking spring	32	Screw
7	Locking in press button	33	Base
8	Microswitch	34	Nylon wire
9	Tapping screw	35	Hollow rivet
10	'Housing rotating spring	36	Eccentric block
11	Second handle rotating button	37	Wire coil cover
12	Aluminium tube	38	Lock nut
13	Second handle	39	Nut
14	Aluminium tube fixing sleeve	40	Wire coil
15	Sleeve	41	Balancing weight
16	Thread bushing	42	Eccentric block spring
17	Aluminium tube	43	Housing cover rotation button
18	Tapping screw	44	Tapping screw
19	Right housing cover	45	Flat washer
20	Right swivelling cover	46	Protect cover
21	Rotating button	47	Blade
22	Handle rotating spring	48	Trimming wheel
23	Decoration cover	49	Wheel axle
24	Location bush	50	Tapping screw
25	Spring wire	51	Connect wire
26	Inductance component	52	Controller

ASSEMBLY DIAGRAM

