

PARTS LIST(73118)

Part	Description	Qty	Part	Description	Qty	Part	Description	Qty
1	AIR FILTER	1	28	OIL LEVER WASHER	1	55	CRANK CASE BOTTON	1
2	SCREW	4	29	OIL LEVER	1	56	NUT	1
3	SCREW	6	30	BOLT	1	57	WASHER	1
4	CIRCLIP	6	31	PRESSURE SWITCH	1	58	CIRCLIP	1
5	CYLINDER HEAD	1	32	BALL VALVE	1	59	SCREW	1
6	REFRIGERATION	1	33	SAFETY VALVE	1	60	NUT	4
7	GASKET	1	34	GAUGE	1	61	CIRCLIP	4
8	VALVE PLATE	2	35	GAUGE	1	62	WASHER	4
9	VALVE CLACK	4	36	PIN VALVE	2	63	SCREW	4
10	GASKET	1	37	FRLTER WITH YEGULATOR	1	64	ELBOW	1
11	CYLINDER	1	38	SCREW	8	65	NON-RETURN VALVE	1
12	CYLINDER HEAD GASKET	1	39	DISCHARGE PIPE	1	66	SCREW	4
13	VALVE PLATE GASKET	1	40	RELEASE PIPE	1	67	WASHER	4
14	PISTON RING	2	41	BRACKET	1	68	CIRCLIP	4
15	PISTON	2	42	NET COVER	1	69	NUT	4
16	PISTON PIN	2	43	HANDHOLD	1	70	TANK	1
17	PISTON PIN RING	4	44	GASKET	1	71	LEAD WHEEL	1
18	CONNECTING ROD	2	45	SCREW	1	72	WHEEL	2
19	CIRCLIP	1	46	TOOTHED WASHER	1	73	WHEEL PIN	2
20	OIL SEALING	1	47	WASHER	1	74	DRAIN COCK	1
21	CRANK	1	48	PULLEY	1	75	PLUG	1
22	BEARING	2	49	SCREW	1	76	CONNECT CABLE	1
23	CRANK CASE	1	50	BREATH PIPE	1	77	STARTUP CAPACITOR	1
24	GASKET	1	51	MOTOR	1	78	RUNNING CAPACITOR	1
25	CRANK CASE COVER	1	52	MOTOR WHEEL	1	79	CAPACITOR COVER	1
26	CIRCLIP	4	53	BELT	1	80	PROTECTOR	1
27	SCREW	4	54	RUBBER GASKET	1			

ASSEMBLY DIAGRAM(73118)

