

## PARTS LIST(73119)

Part	Description	Qty	Part	Description	Qty
1	Air filter	1	53	Belt	1
2	Screw	2	54	Rubber gasket	1
3	Screw	6	55	Crank case button	1
4	Spring washer	14	56	Nut	4
5	Cylinder head	1	58	Fat Washer	4
6	Refrigeration	1	59	Screw	4
7	Gasket	1	60	Nut	8
8	Valve plate	1	61	Flat washer	16
11	Cylinder	1	62	Spring washer	4
12	Cylinder head gasket	1	63	Screw	4
13	Valve plate gasket	1	64	Elbow	1
14	Piston ring	2sets	65	Non-return valve	1
15	Piston	2	66	Screw	4
16	Piston pin	2	70	Tank	1
17	Circlip	4	71	Stem	2
18	Connecting rod	2	72	Wheel8"	4
19	Wave washer	1	73	Wheel pin	4
20	Oil sealing	1	74	Drain cock	1
21	Crank	4	75	Connect cable	1
22	Bearing	2	76	protector	1
23	Crank case	1	77	Bolt	2
24	Gasket	1	78	Flat washer	2
25	Crank case cover	1	79	Nut	2
26	Spring washer	8	80	Protector plate	1
27	Screw	8	81	Bolt	1
28	Oil lever washer	1	82	Double joint	1
29	Oil lever	1	83	Bolt	2
30	Bolt	1	84	Rear cover	1
31	Pressure switch	1	85	Back cover paper pad	1
32	ball valve	3	86	Bolt	4
33	Safety valve	1	87	junction box	1
34	Pressure gauge	1	88	Insulating rubber mat	1
35	Pressure gauge	1	89	Terminal	1
37	Filter with regulator 1/2	1	90	Nut	2
38	Screw	12	91	Terminal box	1
39	Discharge pipe	1	92	Flat key	1
40	Release pipe	1	93	Bolt	6
41	Bracket	1	94	Motor front cover	1
42	Net cover	1	95	Rotor	1
44	Gasket	1	96	Bearing	2
45	Screw	1	97	Wave pad	1
47	Toothed washer	1	98	Motor Rear cover	1
48	Pulley	1	100	Fan	1
49	Screw	6	101	Circlip	1
50	Breath pipe	1	102	Fan cover	1
51	Motor 5.5HP	1	103	Cross screw	3
52	Motor wheel	1	104	Flat washer	4

## ASSEMBLY DIAGRAM(73119)

