

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Pushing block	1	18	Rotor	1
2	Impact iron	1	19	Carbon brush	1
3	Label	1	20	Carbon brush holder	1
4	Right housing	1	21	Capacitance	1
5	4x16 screw	10	22	Inductance	1
6	Screw	1	23	Stator	1
7	Chuck	1	24	Bearing	1
8	Output shaft	1	25	Switch	1
9	Steel ball	1	26	Crimping board	1
10	Steel sleeve	1	27	Sheath	1
11	Clip spring	1	28	Cable	1
12	Gear	1	29	Left housing	1
13	Steel wire circlip	1	30	Label	1
14	Steel ball	1	31	Gauge	1
15	Impact spring	1	32	Handle	1
16	Impactor	1	33	Chuck key	1
17	Bearing	1			

ASSEMBLY DIAGRAM

