

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Screw M5 × 20 - left	1	17	External hexagon bolt M8 × 85	1
2	chuck 13mm	1	18	bracket	1
3	output shaft	1	19	auxiliary handle	1
4	Semicircular key 10 × 3	1	20	Depth guage	1
5	Dust ring	1	21	Plastic cover	1
6	Bearing 6001	1	22	Rubber column 4 × 9	1
7	Circlip for shaft 12	1	23	Cross pan head tapping screw ST4 × 16	10
8	big gear	1	24	Impact block	1
9	Taper spring	1	25	Impact iron sheet	1
10	Flat pad 8.1 × 12 × 0.5	1	26	Motor housing	1
11	688 bearing	1	27	Switch push block	1
12	Oil slinger	1	28	switch	1
13	Impact Bracket ass.	1	29	Carbon brush 5 × 9	2
14	608 bearing	2	30	Capacitance 0.33 μ f	1
15	rotor	1	31	inductance	1
16	stator	1	32	Brush box	2
	Stator insulation end plate	1	33	Cable sheath	1
	Insulation end plate of stator outgoing line	1	34	Cable line	1
			35	key	1

ASSEMBLY DIAGRAM

