

PARTS LIST

part	Description	Qty	part	Description	Qty
1	screw ST4.2×14-F	11	30	belt 4PJ246-1	1
2	brand label	1	31	nut M8	1
3	side cover	1	32	big belt pulley	1
4	screw ST4.2×10	5	33	bearing 6000-2Z	1
5	baffle	1	34	middle cover	1
6	spring $\phi 11 \times \phi 1 \times 3$	1	35	cutter body	1
7	brush box 6×9×20.5	2	36	bearing 607-2Z	1
8	carbon brush	2	37	windshield	1
9	brush box cover 11×9×2.3	2	38	screw ST4.2×55-F	
10	handle upper cover	1	39	stator	1
11	connecting screw rod	1	40	bearing 626-2Z	1
12	handle lower cover	1	41	cable	1
13	steel cover	1	42	cable protector	1
14	steel ball $\phi 2.5$	1	43	cable clamp	1
15	spring $\phi 1.85 \times \phi 0.45 \times 10$	1	44	rotor	1
16	dial	1	45	bearing 608-2Z	1
17	Decorative pieces	1	46	small belt pulley	1
18	spring $\phi 11.5 \times \phi 2 \times 5$	1	47	Inner hexagon wrench 2.5	1
19	front plate	1	48	Open spanner 8	1
20	nut M6	2	49	Attachment block	1
21	housing	1	50	dust pipe	1
22	screw ST4.2×10-F	1	51	support steel	1
23	dust board	1	52	dust bag	1
24	switch	1	53	locked knob	1
25	capacitance	1	54	fence	1
26	handle cover	1	55	angle bracket	1
27	screw ST4.2×30-F	3	56	screw M6×14	1
28	label	1	57	Compression knob	2
29	belt cover	1	58	depth indicator	1

ASSEMBLY DIAGRAM

