

PARTS LIST

NO.	PART NAME	NO.	PART NAME
1	outer flange	26	bearing press cover
2	disc	27	screw M4x10
3	inner flange	28	baffle plate
4	wheel guard	29	armature
5	spindle	30	screw ST3x9
6	wave washer Ø4	31	carbon brush holder
7	screw M4x14	32	carbon brush
8	front cover	33	spring of carbon brush
9	paper gasket	34	insulation ring
10	dustproof ring	35	bearing 607-2RS
11	bearing 6201-2RS	36	bearing bush
12	circlip Ø32	37	capacitor
13	big gear	38	stator
14	needle bearing HK0812	39	motor housing
15	screw ST4x18	40	button
16	side handle	41	lever
17	lock cap	42	switch
18	spring of shaft lock	43	screw ST4x14
19	lock pin	44	cord clamp
20	head case	46	cord sleeve
21	nut M6	47	rear cover
22	small gear	48	screw ST4*18
23	bearing 608-2RS	49	cord
24	washer	50	spanner
25	paper gasket		

ASSEMBLY DIAGRAM

